

JASCO

Premium Quality Since 1952

PRE-PAINT PREPARATION

LIQUID SANDER

BEFORE YOU
PAINT OR REFINISH!

1 QUART

946 mL

PREPS & DEGLOSSES – NO SANDING NEEDED

CAUTION! EYE IRRITANT. HARMFUL IF SWALLOWED.
Read other cautions on back panel.

CAUTION: EYE IRRITANT. HARMFUL IF SWALLOWED.
Contains Dibasic Esters and 2-Butoxyethanol. Avoid contact with eyes and prolonged contact with skin. Use only with adequate ventilation. Avoid breathing vapors. Do not ingest.

FIRST AID: In case of eye contact, flush thoroughly with water for 15 minutes and get medical attention. In case of skin contact, wash thoroughly with soap and water. If irritation persists, get medical attention. If swallowed, contact poison control center, hospital emergency room or physician immediately.

KEEP OUT OF REACH OF CHILDREN

For assistance call:
The Barr Help Line 1-800-398-3892
Monday - Friday 8am - 4:30 pm Central Time

Item #QJLS00402



JASCO® Liquid Sander is a ready-to-use liquid deglosser that saves time and labor. This product is formulated for use by the professional and homeowner who desires to save time and effort while achieving a high quality paint application on previously painted and glossy surfaces. Liquid Sander works in one easy application WITHOUT MIXING, WASHING OR SANDING to degloss old coated surfaces. This allows NEW paint, enamel, varnish, urethane, lacquer, shellac, stain or wallpaper to bond. Its etching and deglossing action forms a perfect base for new paint or coating. Low odor and non-flammability make it ideal for use in kitchens or bathrooms as well as other interior/exterior applications.

USES:

- DEGLOSSES • ETCHES • REMOVES DIRT, WAX, INK, TAR
- FOR PAINTED & VARNISHED SURFACES

FEATURES:

- EASY TO USE • ELIMINATES SANDING – SAVES TIME • IMPROVES PAINT BOND
- NON-FLAMMABLE • LOW ODOR

Unfinished Wood: Removes dirt, pencil, crayon, ink, dust, scuffs and finger and heel marks without raising grain of wood.

Panels & Floors: Removes wax, tar, dirt, dust, shoe and furniture marks. Always wipe in direction of grain.

Always test first on an inconspicuous surface for compatibility and on nearby surfaces that are not to be refinished, as it will degloss most surfaces.

DIRECTIONS: Wear chemical-resistant gloves and chemical splash goggles.

APPLY: This product is premixed. Shake well before use. Apply Liquid Sander to a coarse cloth or brush (or on an abrasive pad or steel wool on heavily soiled, waxed or rough surfaces). Rub the surface until clean and deglossed.

REMOVE: Let stand for a few minutes, then wipe off dust, dirt, or wax with a clean cloth. Heavily soiled or waxed surfaces may need additional applications to remove all residue.

WAIT: Let all surfaces completely dry. Typically, they will be dry to the touch in 2 hours.

FINISH: Refinish when dry or before surface becomes dusty or dirty again. If it does, rewipe with Liquid Sander and refinish.

CLEANUP: Clean up tools and any spills with water.

© 2008 W.M. Barr & Co., Inc.
Memphis, TN 38113
www.jasco-help.com

All rights reserved.

Label design is a trademark of W.M. Barr & Co., Inc.

J4944